
SECTION IV

AIR OPERATED ROLL LIFTER





INDEX NO.	DESCRIPTION
1 2 3 4 5 6 7 8 9 10 11 12	Cam Switch - Limit, Snap-lock Bracket - Switch Screw - Socket-head, Cap Screw - Hex-head Cap Plate - Ball Clamp Post - Large Ball Head Plate - Ball Base Valve - Air Cylinder - Air End - Air Cylinder Nut - Jam

INDEX NO.	DESCRIPTION
13	Bracket - Air Cylinder
14	Bushing - Air Cylinder Bracket
15	Pin - Fulcrum
16	Ring - Retainer
17	Bushing - Fulcrum Pin
18	Pin - Fulcrum
19	Ring - Retainer
20	Roller - Air Cylinder End Follower
21	Lever - Lifter
. 22	Regulator - Pressure
23	Lubricator
24	Filter - Manual Drain